## Installation



Use the universal opening cutter to make accurate conduit entries for the appropriate conduit sizes.



Join the housing components to correspond to the ceiling thickness and installation depth.



Now insert the complete housing, including the installation into the opening or drilling hole. Then .



... fill the free space with concrete and compact it. A formwork board fitted underneath prevents the concrete from running out.

## HaloX-O housing for drilling holes in solid ceilings

- · for retrofitting in solid ceilings
- 1-piece
- required hole size  $\varnothing$  150-160 mm
- Take into consideration the ceiling thickness - at least 3 cm concrete cover is needed on top of the box



Diameter	130 mm
Art. No.	1290-30
Inner nacking / shinning	/ 10